








AVK GATE VALVE AND EXTENSION SPINDLE

Mounting instruction / Montagevejledning
Einbauanleitung / Instruction de montage



AVK gate valve and extension spindle

Part No.: XXXXXXXXXX



AVK

www.avkvalves.eu



**DN 50-125:
Max. 200 Nm**

**DN 150-400:
Max. 400 Nm**

**DN 450-600:
Max. 500 Nm**

Expect... **AVK**